

4 channel running light

Features:


K8032

- ☑ Adjustable speed.
- Suited for inductive loads.
- 4 channels with LED indicator.
- Ideal for disco effects.
- ☑ Noise suppressed according to EN55015.

Specifications:

- AC Power: 110 to 240 VAC.
- Auto frequency detection: 50/60Hz.
- Max load per channel 2A: 200W (110 125VAC) 400W (220 - 240VAC)
- Adjustable speed: 0,2 to 3Hz.
- Dimensions: 100 x 82 x 35mm / 4 x 3,3 x 1,4"

Modifications reserved.



VELLEMAN Components NV Legen Heirweg 33 9890 Gavere Belgium Europe www.velleman.be www.velleman-kit.com



1. Assembly (Skipping this can lead to troubles!)


Ok, so we have your attention. These hints will help you to make this project successful. Read them carefully.

1.1 Make sure you have the right tools:

A good quality soldering iron (25-40W) with a small tip.




Wipe it often on a wet sponge or cloth, to keep it clean; then apply solder to the tip, to give it a wet look. This is called 'thinning' and will protect the tip, and enables you to make good connections. When solder rolls off the tip. it needs cleaning.





A diagonal cutter to trim excess wires. To avoid injury when cutting excess leads, hold the lead so they cannot fly towards the eyes.



place.

Small blade and Phillips screwdrivers. A basic range is fine.



For some projects, a basic multi-meter is required, or might be handy



1.2 Assembly Hints:


- ⇒ Make sure the skill level matches your experience, to avoid disappointments.
- ⇒ Follow the instructions carefully. Read and understand the entire step before you perform each operation.
- ⇒ Perform the assembly in the correct order as stated in this manual
- ⇒ Position all parts on the PCB (Printed Circuit Board) as shown on the drawings.
- ⇒ Values on the circuit diagram are subject to changes.
- ⇒ Values in this assembly guide are correct*
- ⇒ Use the check-boxes to mark your progress.
- ⇒ Please read the included information on safety and customer service

^{*} Typographical inaccuracies excluded. Always look for possible last minute manual updates, indicated as 'NOTE' on a separate leaflet.



1.3 Soldering Hints:


Mount the component against the PCB surface and carefully solder the leads



Make sure the solder joints are cone-shaped and shiny





Trim excess leads as close as possible to the solder joint




AXIAL COMPONENTS ARE TAPED IN THE CORRECT MOUNTING SEQUENCE!










COLOR= 2...5

	ОООШ	0	_	2	3	4	2	9	7	œ	6	٧	В
N	KLEUR C KODE O D	Zwart	Bruin	Rood	Oranje	Geel	Groen	Blauw	Paars	Grijs	Wit	Zilver	Pnog
ш	CODIFI- CATION DES COU- LEURS	Noir	Brun	Rouge	Orange	Jaune	Vert	Bleu	Violet	Gris	Blanc	Argent	or
GB	COLOUR COBIFI- CODE CATION DES CO LEURS	Black	Brown	Red	Orange	Yellow	Green	Blue	Purple	Grey	White	Silver	plog
D	FARB KODE	Schwarz	Braun	Rot	Orange	Gelb	Grün	Blau	Violet	Grau	Weiss	Silber	Plob
z	FARGE- KODE	Sort	Brun	Rød	Orange	Gul	Grønn	Blå	Violet	Grå	Hvidt	Sølv	IpIn9
DK	FARVE- KODE	Sort	Brun	Rød	Orange	Gul	Grøn	Blå	Violet	Grå	Hvid	Sølv	guld
S	FÄRG SCHEMA	Svart	Brun	Röd	Orange	Gul	Grön	Blå	Lila	Grå	Vit	Silver	PINĐ
SF	väri Koodi	Musta	Ruskea	Punainen		Keltainen	Vihreä	Sininen	Purppura	Harmaa	Valkoinen	Нореа	Kulta
ш	CODIGO DE COL- ORES	Negro	Marrón	Rojo	Naranjado Oranssi	Amarillo	Verde	Azul	Morado	Gris	Blanco	Plata	Oro
Ь	CODICE CODIGO	Preto	Castanho	Encarnado Rojo	Laranja	Amarelo	Verde	Azul	Violeta	Cinzento	Branco	Prateado	Dourado
-	согове	Nero	Marrone	Rosso	Aranciato	Giallo	Verde	Blu	Viola	Grigio	Bianco	Argento	Oro
	ОООШ	0	1	2	3	4	2	9	2	8	6	٧	В




1. 1/4W Resistors




- □ R4: 3K3 (3-3-2-B)
- ☐ R6: 270 (2-7-1-B) ☐ R7: 270 (2-7-1-B)
- □ R8: 270 (2-7-1-B)□ R9: 270 (2-7-1-B)

2. 1/2W Resistors



- R2: 220K (2-2-4-B-9)
 - ☐ R3: 220K (2-2-4-B-9)☐ R5: 470K (4-7-4-B-9)
- □ R10: 47 (4-7-0-B-9)
- □ R11: 47 (4-7-0-B-9)
 - R12: 47 (4-7-0-B-9)
 - R13: 47 (4-7-0-B-9)

3. Diodes Watch the polarity!



- □ D1:1N4007
- □ D2:1N4007

4. Zenerdiode Watch the polarity!



□ ZD1: ZB12V0

5. IC socket, Watch the position of the notch!






□ IC1:8P

vellemen

6. 1W Resistor



7. Capacitors





- □ C3:100n (104)
- □ C4:100n (104)
- □ C6:100p (101)
- ☐ C7:10n (103)





- □ C8: 10nF/600V
- □ C9: 10nF / 600V
- ☐ C10: 10nF / 600V
- ☐ C11: 10nF / 600V

8. PCB tabs



- ☐ SK1 : Power (2X)
- ☐ SK2 : Out1 (2X)
- □ SK3: Out2 (2X)
 □ SK4: Out3 (2X)
- ☐ SK5 : Out4 (2X)

9. Trim potentiometer



☐ RV1:100K

10. Transistors.



■ T1 : BC547

11. Voltage Regulator



■ VR1 : UA78L05



12. Electrolytic Capacitors. Watch the polarity!



□ C5:10µF/35V

13. Fuseholder + Fuse



☐ F1 : 2A (slow)

14. Triac.

The back side corresponds to the thick line.




□ TR1 : TIC225M□ TR2 : TIC225M

☐ TR2 : TIC225M ☐ TR3 : TIC225M


☐ TR4 : TIC225M

15. Capacitors



□ C1.08011/000V

16. LED's. Watch the polarity!




□ LD1: 3mm Red□ LD2: 3mm Red

☐ LD2: 3mm Red☐ LD3: 3mm Red

LD3: 3mm Red


17. IC, Check the position of the notch!



IC1: PIC12C508A



18. Hook- up and use



- ☐ Solder an AC cable to the SK1 pins (AC Power).
- Solder the cables of each lampholder to the appropriate pins.

As this kit is shipped to different countries, their is no AC plug supplied. You will need to attach a plug that matches your electrical system.


You can adjust the running speed by turning the trimmer "RV1". Each LED will light up when a channel is activated.

Inspect the complete assembly once more before applying power to the unit!

9




19. PCB layout.





20. Schematic diagram.



VELLEMAN Components NV Legen Heirweg 33 9890 Gavere Belgium Europe www.velleman.be www.velleman-kit.com

Modifications and typographical errors reserved © Velleman Components nv. H8032IP - 2002 - ED1